

Hydraulic Jacks

ECI Safety

Hydraulic Jacks

- Read Owners Manual
 - [BVA Hydr Cylinder Instruction Manual](#)
- Select appropriate capacity
- Install in-line pressure gage
- Inspect before use:
 - No Dents, leaks, broken parts




Figure 1 - Typical Cylinder Components

Hydraulic Jacks



Set Up & Jacking:

- Firm & level surfaces
- Center over support and load point
- Apply lift force evenly and gradually
- Watch for sudden release of pent up energy in a connection

Jacks - Blocking

Immediately block the load after it is lifted. Put a block under the base of the jack when the foundation is not firm, and place a block between the jack cap and load if the cap might slip.



More Jacks

